



Spare parts list for RELT3525			
Pozice	Obj.číslo	Popis	Počet ks
1	6001-212001	Left motor housing	1
2	6070-212001	Protective cover	1
3	6030-210001	Blade	1
4	6038-212001	PVC tube	1
5	6002-212001	Right motor housing	1
6	6SJAC04-14D	Screw ST4x14	1
7	6037-212001	Stopple	1
8	6058-212001	Lock button of tube	1
9	6038-212002	Aluminum tube	1
10	6094-212001	Right auxiliary handle	1
11	6NA06D0	M6 nut	1
12	6058-213001	Unlock button of handle	1
13	6137-212001	Right main handle	1
14	6060-213002	Spring 2	1
15	6060-213004	Spring 4	1
16	6058-213002	Lock-off button	1
17	6157-213001	Switch trigger	1
18	6032-210001	Switch	1
19	6033-210001	Capacitance	1
20	6130-210001	Wiring terminal	1
21	6SJAC04-12D	Screw ST4x12	2
22	6053-210001	Cable clamp	2
23	6136-212001	Left main handle	1
24	6023-210002	Cable retainer	1
25	6029-210001	Cable	1
26	6SFDD06-60D	Bolt M6x60	1
27	6094-212002	Left auxiliary handle	1
28	6027-212001	Connect cable	1
29	6004-212005	Motor assembly	1
30	6049-210001	Cutting head socket	1
31	6RE04-07A	Copper rivet	2
32	6NC05D0	Nut M5	1
33	6081-212001	Stopple	1
34	6060-210001	Spring	1
35	6139-210001	Spool	1
36	6127-210001	Nylon thread DIA.1.2 x 6m	1
37	6023-210001	Spool cover	1