





Ser.NO.	DWG NO.	Part No.	description	Qty
1	TTR260S.03.08-00		flexible shaft	1
2	TTR260SJ.03.01-3	01.04.0481	spring washer	1
3	TTR260S.03.00-1		curve tubing	1
4	TTR260S.03.00-2		plastic liner	1
5	GB/T6170	01.03.0192	nut M5	2
6	GB/T70.1	01.01.3011	screw M5x8	1
7	GB/T93	01.04.0091	lock washer 5	1
8	GB/T97.1	01.04.0121	plate washer 5	1
9	GB/T70.1	01.01.3251	screw M5x14	2
10	GB/T93	01.04.0091	lock washer 5	2
11	GB/T97.1	01.04.0121	plate washer 5	2
12	TTR260SJ.06.00-2	04.08.03.00208	clamp \ guard	1
13	TTR260SJ.06.00-1	04.08.03.00108	plastic guard	1
14	TTR260SJ.06.00-3	06.06.756	cutting blade	1
15	GB/T70.1	01.01.3251	screw M5x14	2
16	GB/T93	01.04.0091	lock washer 5	2
17	GB/T97.1	01.04.0121	plate washer 5	2
18	TTR260SJ.02.01-00	06.06.753	string head assembly	1
19	TTR260SJ.03.04-3		nut \ cover	1
20	TTR260SJ.03.04-1		housing \ bearing	1
21	TTR260SJ.03.06-00		bearing 11x15x12.5	3
22	TTR260SJ.03.04-2		shaft \ output	1
23	TTR260SJ.03.04-00	00.06.01.001	connector	1
24	TTR260SJ.03.05-2	00.06.01.003	eyelet	1
25	TBC430S.05.01-11	03.06.1.007	front handle	1
26	GB/T70.1		screw M5x30	4
27	GB/T93		lock washer 5	4
28	GB/T97.1		plate washer 5	4
29	TBC430S.05.01-1		front handle	1
30	TBC430S.05.01-3		rubber\ handle	1
31	TBC430S.05.01-2		front handle bar	1
32	GB/T6170		nut M5	4
33	TTR260SJ.02.00-1		foam grip	1
34	GB/T6170		nut M5	2
35	TBC430S.05.02-2		half handle \ LH	1
36	TBC430S.05.02-4		spring \ trigger	1
37	TBC430S.05.05-00		wire cable A	1
38	TBC430S.05.06-00		wire cable B	1
39	TBC430S.05.02-8		wire tube	1
40	TBC430S.05.03-00		throttl cable assembly	1
41	TBC430S.05.02-1		half handle \ RH	1
42	GB/T70.1		screw M5x22	2
43	GB/T845		ST screw ST4.2x19	4
44	TBC430S.05.02-3		trigger	1
45	TBC430S.05.04-00		switch	1
46	TBC430S.05.02-5		lock trigger	1
47	TBC430S.05.02-00	03.06.1.008	control handle assembly	1



Ref	Part No	description	Qty
1	TBC260D.01.08.00-1	air box cover	1
2	TBC260D.01.08.00-2	sponge	1
3	GB/T70.1	screw M5x50	2
4	GB/T93	locked washer 5	2
		flat washer 5	
5	GB/T97.1	flat washer 5	2
		flat washer 5	
6	TBC330D.01.08.01-00	air box base	1
7	TBC260D.01.06.00-00	carburetor	1
8	GJB25D.01.00.00-6	gasket \ carburetor	1
9	GB/T70.1	screw M5x20	2
10	GB/T93	locked washer 5	2
		flat washer 5	
11	GB/T97.1	flat washer 5	2
		flat washer 5	
12	TBC260D.01.00.01-00	admitting pipe	1
13	TBC260D.01.00.00-5	gasket	1
14	GB/T70.1	screw M5x16	3
15	GB/T93	locked washer 5	3
		flat washer 5	
16	GB/T97.1	flat washer 5	3
		flat washer 5	
17	TBC260D.01.12.00-00	starter assembly	1
18	TBC260D.01.00.02-00	start reel	1
19	GB/T97.1	washer 8	1
20	TBC260D.01.01.00-2	crank case RH side	1
	TBC260D.01.01.00-2		
21	YD38-3.01.01.02-00	OIL-SEAL 12x22x7	1
22	GB/T276	bearing 6001	1
23	TBC260D.01.03.01-00	crank shaft assembly	1
24	GB/T276	bearing 6001	1
25	YD38-3.01.01.02-00	OIL-SEAL 12x22x7	1
26	TBC260D.01.01.00-3	gasket \ crank case	1
27	TBC260D.01.01.00-1	crank case LH side	1
28	TBC260D.01.10.00-00	magneto rotor	1
29	GB/T6177.2	flange nut M8x1	1
30	GJB25D.01.00.00-15	flat washer	2
31	TBC260D.01.00.03-00	clutch assembly	1
32	GB/T119.2	pin $\phi 4 \times 12$	2
33	TBC260D.01.01.00-4	fan cover	1
34	GB/T70.1	screw M5x20	4
35	GB/T93	locked washer 5	5
		flat washer 5	
36	GB/T97.1	flat washer 5	5
		flat washer 5	
37	GB/T70.1	screw M5x12	1
38	GJB25D.01.00.00-14	bolt \ clutch	2
	GJB25D.01.00.00-14		
39	TBC260D.01.11.01-00	ignition	1
40	TBC260D.01.11.02-00	wire	1
41	GB/T70.1	screw M5x30	4
42	YD45.01.11.04-00	Spark Plug	1
43	GB/T93	locked washer 5	4
		flat washer 5	
44	GB/T97.1	flat washer 5	4
		flat washer 5	
45	GB/T119.2	pin $\phi 5 \times 10$	2
46	GB/T1099	key 3x3.5x10	1
47	YD38-3.01.03.00-4	circlip \ Piston pin	1
48	TBC260D.01.03.03-00	bearing 6001 8x11x11	1
49	GJB25D.01.03.00-2	piston pin	1
50	YD38-3.01.03.00-4	circlip \ Piston pin	1
51	GJB25D.01.03.02-00	piston	1
52	GJB25D.01.03.00-1	piston ring	2
53	TBC260D.01.00.00-4	gasket \ cylinder	1
54	TBC260D.01.00.00-1	cylinder	1
55	TBC260D.01.00.00-3	plastic plate	1

56	GB/T97.1	flat washer 5	4
		flat washer 5	
57	GB/T93	locked washer 5	4
		flat washer 5	
58	GB/T70.1	screw M5x20	4
59	GB/T97.1	flat washer 5	1
		flat washer 5	
60	GB/T93	locked washer 5	1
		flat washer 5	
61	GB/T70.1	screw M5x12	1
62	TBC260D.01.00.00-2	top housing	1
63	TBC430D.01.13.00-5	fuel tube	1
64	TBC430D.01.13.00-3	retainer . fuel tube	1
65	TBC430D.01.13.00-4	fuel tube	1
66	TD38-3.03.04-00	filter fuel	1
67	TBC430D.01.13.01-00	fuel tank cover ass'y	1
68	TBC260D.01.13.00-1	fuel tank	1
69	GB/T70.1	screw M5x55	2
70	GB/T93	locked washer 5	2
		flat washer 5	
71	GB/T97.1	flat washer 5	2
		flat washer 5	
72	TBC260D.01.09.00-00	muffler	1
	GB/T894.1	circlip 15	1
73	TBC260D.01.13.00-00	fuel tank assembly	1
	TBC430D.02.00-1	clutch drum housing	1
74	TBC260D.01.00.00-6	gasket \ muffler	1
	TBC430D.02.00-2	rubber	1
75	TBC260D.01.00.00-7	fuel tank housing	1
	GB/T70.1		1
76	GB/T97.1	flat washer 5	3
	GB/T97.1	flat washer 5	2
77	GB/T93	locked washer 5	3
	GB/T97.1	flat washer 5	2
78	GB/T70.1	screw M5x25	3
79	TBC260D.01.14.01-00	clutch drum assembly	1
	TBC430D.02.00-4	clamp RH	1
80	GB/T893.1	circlip 35	1
	TBC430D.02.00-3	circlip 35	1
81	GB/T276	bearing 6202	1
	GB/T70.1	screw M6x20	4
82	GB/T894.1	circlip 15	1
	GB/T93	locked washer 6	4
83	TBC260D.01.14.00-1	clutch drum housing	1
	TBC430D.02.00-4	clutch drum housing	4
84	TBC430D.01.14.00-2	rubber	1
	TBC430D.02.00-00	clutch drum assembly	1
85	GB/T70.1	screw M5x12	1
	TBC430D.02.00-4	clamp RH	1
86	GB/T70.1	screw M5x25	2
	TBC430D.02.00-4	clamp RH	1
87	GB/T93	locked washer 5	3
	GB/T97.1	flat washer 5	2
88	GB/T97.1	flat washer 5	3
	GB/T97.1	flat washer 5	2
89	TBC430D.01.14.00-4	clamp RH	1
	TBC430D.02.00-00	clamp RH	1
90	TBC430D.01.14.00-3	clamp LH	1
	TBC430D.02.00-00	clamp LH	1
91	GB/T70.1	screw M6x20	4
	GB/T70.1	screw M6x20	4
92	GB/T93	locked washer 6	4
	GB/T93	locked washer 6	4
93	GB/T97.1	flat washer 6	4
	GB/T97.1	flat washer 6	4
94	TBC260D.01.14.00-00	clutch drum assembly	1
	GB/T93	clutch drum assembly	4