






Pozice	Obj.číslo	Popis	Počet
1	20084362	CHOKE KNOB	1
2	20051803	SCREW M4×16	2
3	20061531	WASHER 4	2
4	20071440	THROTTLE CABLE	1
5	20084880	ENGINE	1
6	20061285	TAPPING SCREW 3/8"-16-1 1/4"	3
7	20070519	FLAT KEY 6.35×30	1
8	20071187	Engine pulley weldment	1
9	20061482	WASHER 6	1
10	20088530	SUPPORT	1
11	20082800	Tapping screw M6×16	6
12	20085206	Electric clutch	1
13	20085758	Clutch Step Bushing	1
14	20061455	Spring washer 7/16"	1
15	20062410	BOLT, 7/16"-20- 3",UNF	1
16	20085121	Clutch clamp plate	1
17	20061348	FLANGE LOCK NUT M8	3
18	20085859	Clutch baffle (small bin)	1
19	20061299	BOLT M8×20	2
20	20061254	FLANGE BOLT M8×40	1
21	20060850	SCREW 5/16"-18 -3/4"	4

22	20061453	Spring washer 5/16"	4
23	20084879	MUFFLE	1
24	20070868	GASKET	2
25	20085348	FRONT SHIELD	1
26	20061539	BIG WASHER 6	2
27	20061197	BOLT M6×25	2
28	20085755	WASHER Φ6.2*Φ12*6	4
29	20084296	BRACKET	1
30	20061346	FLANGE LOCK NUT M6	2
31	20082799	FLANGE BOLT 5/16-18TX3/4	2
32	20061541	BIG WASHER 8	2




Pozice	Obj.číslo	Popis	Počet
1	20059754	FUEL TANK CAP LEVER	1
2	20071493	O RING	1
3	20059760	FUEL TANK CAP	1
4	20059763	FUEL TANK CAP FILTER	1
5	20071494	FUEL TANK CAP SEAL	1
6	20071676	GASKET 6×25×1.5	4
7	20059764	FUEL TANK CAP SPRING	1
8	20061445	WASHER 5	1
9	20059765	SPLIT PIN	1
10	20059766	FILTER CAP	1
11	20071228	FUEL TANK	1
12	20082800	Tapping screwM6*1	3
13	20062744	CLIP φ10	1
14	20070865	FUEL HOSE	1
15	20071161	CLIP φ10	1
16	20071747	FUEL TANK CAP ASY	1




Pozice	Obj.číslo	Popis	Počet
1	20061275	FLANGE BOLT M8×60	1
2	20070780	Bushing	2
3	20084436	SPACER 8x18x33	1
4	20062521	FLANGE BOLT M10×1.25×40	1
5	20084440	DRIVING TENTION ARM WELDMENT	1
6	20070875	SPRING	1
7	20061336	FLANGE NUT M8	1
8	20071180	TENTION PULLEY BUSHING	1
9	20071213	TENTION PULLEY	1
10	20061403	LOCK NUT M10×1.25	6
11	20070536	TENTION PULLEY	1
12	20061626	BEARING 6301-2RS	1
13	20061549	SNAP RING 37	1
14	20082800	Tapping screwM6*16	4
15	20061284	FLANGE BOLT M10×1.25×35	1
16	20088482	GUIDE PULLEY BASE PLATE	1
17	20088483	WASHER 10x18x7	1
18	20061542	BIG WASHER 10	1
19	20062499	WASHER 27x10.5x5	1
20	20084441	Tensioning wheel bolt	1
21	20085198	V belt LG4-1030	1
22	20062515	FLANGE BOLT M10×1.25×50	2
23	20071208	DRIVING GUIDE PULLEY	3

24	20084442	GUIDE PULLEY CUSHION SLEEVE	2
25	20061445	WASHER 5	1
26	20059765	SPLIT PIN	1
27	20085193	Oil discharge push rod (K46)	1




Pozice	Obj.číslo	Popis	Počet
1	20061274	FLANGE BOLT M8×20	4
2	20084428	Right foot step suspension plate	1
3	20061348	FLANGE LOCK NUT M8	18
4	20084430	Right pedal	1
5	20084393	Foot pad right	1
6	20061385	Hexagon flange lock nut M6	8
7	20082799	FLANGE BOLT 5/16-18TX3/4	26
8	20084427	Foot forward support right	1
9	20061201	FLANGE BOLT M6×16	2
10	20070916	BUSHING	2
11	20061196	FLANGE BOLT M6×25	2
12	20088080	Frame Weldment	1
13	20084375	Right side of hood bracket	1
14	20088534	Collision bar extension right	1
15	20085086	bumper	1
16	20061299	BOLT M8×20	10
17	20084403	Left side of hood bracket	1
18	20088532	Collision bar extension left	1
19	20082800	Tapping screw M6*16	14
20	20084384	Pillar rear cover support plate	2
21	20084401	Column frame welding parts	1
22	20061289	Bolt M6X16	2
23	20084422	Foot forward support left	1
24	20084429	Left pedal	1
25	20084388	Foot pad left	1

26	20084417	Seat font crossbeam weldment	1
27	20084399	Side standing plate	2
28	20084414	Left foot step suspension plate	1
29	20084396	Left side of trapezoidal connecting plate weldment	1
30	20084385	Rear baffle bracket	2
31	20084420	Rotaing bracket right weldment	1
32	20084419	Rotaing bracket left weldment	1
33	20061513	WASHER 10	4
34	20061471	SPRING WASHER 10	4
35	20061316	Hexagonal head bolt M10x1.5x30, GB/T5783	4
36	20084387	Tailgate	1
37	20084390	Pull hook seat left	1
38	20085354	Hook L	1
39	20087837	Hook R	1
40	20070649	Pin screw M6	2
41	20061298	FLANGE BOLT M8×25	2
42	20070645	Straw bag buckle tension spring	2
43	20084418	Rear strut left	1
44	20084412	Rear strut right	1
45	20084421	Step bolt M8*20	2
46	20084392	Right side of trapezoidal connecting plate weldment	1
47	20084381	Pull hook seat right	1




Pozice	Obj.číslo	Popis	Počet
1	20068187	HUB COVER	2
2	20061488	SNAP RING 19	2
3	20071143	WASHER $\phi 20 \times \phi 43 \times 3$	2
4	20071144	WASHER	4
5	20086529	Front wheel assembly	2
5,1	20083980	FRONT WHEEL ASSEMBLY	2
5,2	20071149	FRONT WHEEL ASSEMBLY	2
5,3	20061665		2
5,4	20061595	BEARING 61904-2RZ	4
6	20084372	Front Axle RH	1
7	20061444	WASHER 20	2
8	20070566	BUSHING	4
9	20084364	FRONT AXLE WELDMENT	1
10	20061348	FLANGE LOCK NUT M8	1
11	20070941	TURNNG ARM	1
12	20055114	WASHER	2
13	20061533	SPRING WASHER 8	2
14	20061291	BOLT M8×20	2
15	20061256	FLANGE BOLT M8×45	1
16	20061359	FLANGE LOCK NUT M12×1.25	1
17	20084370	LINER TUBE	1
18	20061649	OIL INJECTION NOZZLE	2
19	20061482	WASHER6	2
20	20085752	FLANGE BOLT M12×1.25×55	1
21	20084367	Front Axle LH	1




Pozice	Obj.číslo	Popis	Počet
1	20085366	JOINT BEARING M10	1
2	20061399	NUT M10	2
3	20084461	STEERING DRAG ROD	1
4	20061348	FLANGE LOCK NUT M8	7
5	20084463	SQUARE HOLE CARD BOARD	1
6	20061299	SCREW M8×20	2
7	20061298	FLANGE BOLT M8×25	6
8	20083389	Couplings	1
9	20082643	HATCH BUSHING	1
10	20061548	SNAP RING 15	1
11	20084458	Steering column	1
12	20061419	LOCK NUT M10	1
13	20084462	ELASTIC RUBBER BUSH	2
14	20084456	STEERING DRAG ROD	1
15	20084459	PIN SCREW M8×28	2
16	20084457	STEERING GEAR LEFT	1
17	20061569	PIN 6×26	1
18	20061437	WASHER 16	2
19	20070612	HEXAGON BUSHING	1
20	20071127	BUSHING	1
21	20085898	SNAP RING 16	1
22	20070939	TIE PLATE	1
23	20070932	BUSHING	2
24	20084464	STEERING GEAR PLATE WELDMENT	1
25	20070942	DOUBLE HOLE BOARD	1
26	20061641	JOINT BEARING SIJK10C	1
27	20061403	LOCK NUT M10×1.25	1
28	20084465	STEERING WHEEL ROD A	1
29	20051824	Tapping screw ST4.8x16	2

30	20082707	STEERING WHEEL	1
31	20079969	Splined Hub	1
32	20082683	WASHER	1
33	20082679	STEERING WHEEL CAP	1




Pozice	Obj.číslo	Popis	Počet
1	20068187	HUB COVER	2
2	20061430	RETAINER RING 15	2
3	20071143	WASHER $\phi 20 \times \phi 43 \times 3$	4
4	20086530	REAR WHEEL ASSEMBLY	2
4,1	20061665		2
4,2	20060810		2
4,3	20083979		2
5	20071174	FLAT KEY 4.85×60	2
6	20061254	FLANGE BOLT M8×40	1
7	20061274	FLANGE BOLT M8×20	1
8	20085196	Rear fixed plate of hydraulic axle (K46)	1
9	20061348	FLANGE LOCK NUT M8	6
10	20086645	TRANSAXLE, HYDRO, TTC, K46DR	1
11	20086191	Bow-tie Cotter pin 2(K46)	1
12	20070582	Cotter pin	4
13	20061419	LOCK NUT M10	1
14	20061385	FLANGE LOCK NUT M6	2
15	20085192	Cable support	1
16	20061289	Bolt M6X16	2
17	20088865	Brake Cable (k46)	1
18	20068229	REVERSE PEDAL	1
19	20084591	Foot lever weldment	1
20	20061310	FLANGE BOLT 8×65	4


21	20070576	SPRING PIN	1
22	20061369	Hexagon nut 10X1.25	4
23	20085748	Pull rod pin	1
24	20061403	LOCK NUT M10×1.25	1
25	20085194	Traveling pull rod (K46)	1
26	20061497	Washer 10	1
27	20088861	Cable fixing plate	1
28	20082800	Tapping screwM6*16	4
29	20084574	Brake reset tension spring	1
30	20084532	U-SHAPED CLAMP	2
31	20082799	FLANGE BOLT 5/16-18TX3/4	4
32	20089015	brak switch sert plate	1
33	20068230	FORWARD PEDAL	1
34	20073313	WASHER 16.5x30x1.5	1
35	20061482	WASHER 6	1
36	20061250	FLANGE BOLT M8×25	1
37	20088842	step cover	1
38	20089014	parking hook	1
39	20061541	BIG WASHER8	1
40	20088846	Drag Link,Brake Parking	1
41	20070894	CLUTCH LEVER SPRING	1
42	20084583	BRAKE HANDLE	1
43	20084581	U BOLT	1
44	20088844	BRAKE FOOT BAR WELDMENT(Hydraulic Pressure)	1
45	20082728	BRAKE PEDAL	1



Pozice	Obj.číslo	Popis	Počet
1	20061348	FLANGE LOCK NUT M8	6
2	20084447	SEAT BACK BEAM	1
3	20061274	FLANGE BOLT M8×20	4
4	20070964	SEAT SPRING	2
5	20061541	BIG WASHER	6
6	20061298	FLANGE BOLT M8×25	6
7	20068240	SPRING CAP	2
8	20085449	justable seat base plate	1
9	20088755	Seat screws	2
10	20088754	Seat cushion strip	2
11	20082800	Tapping screwM6*16	2
12	20088756	Seat switcch components	1
13	20088757	SEAT ZIZY2-2	1
14	20085377	SPRING ϕ 1.5× ϕ 16	1
15	20085375	Seat adjustment plate	1




Pozice	Obj.číslo	Popis	Počet
1	20061348	FLANGE LOCK NUT M8	4
2	20061541	BIG WASHER	4
3	20084556	FRONT STAY BAR WELDMENT	2
4	20084557	FRONT RIGHT DERRICK	1
5	20061369	Hexagon nut 10X1.25	2
6	20084533	PIN	1
7	20061405	FLANGE LOCK NUT M10×1.25	3
8	20061497	WASHER 10	10
9	20070576	SPRING PIN	10
10	20084559	LIFTING LINK ROD WELDMENT(REAR DISCHARGE)	1
11	20084539	REAR ARM WELDMENT(Rear)	1
12	20084553	U DERRICK WELDMENT	1
13	20084560	FRONT ARM WELDMENT	1
14	20082799	FLANGE BOLT 5/16-18TX3/4	10
15	20084532	U-SHAPED CLAMP	4
16	20070967	ADJUSTING PIN	1
17	20084563	LIFTING PULL ROD(REAR DISCHARGE)	1
18	20082800	Tapping screw M6*16	2
19	20085316	Spring hanging plate TTM86, electroplating	1
20	20070900	HANDLE	1
21	20084549	RATCHET PLATE	1
22	20084564	LIFTING HELPING SPRING	1
23	20071251	Cotter pin $\phi 3$	1
24	20062529	WASHER 14x1.5	1
25	20071354	RIGHT SPRING	1
26	20084535	LEVEL WELDMENT	1
27	20061473	RETAINER RING 12	1
28	20070612	HEXAGON BUSHING	2
29	20084537	Deck Lift Shift Assemble	1
30	20085750	Pin joint TTM86S, electroplated	1
31	20085865	Rear left suspension rod electroplating	1
32	20085747	Rear right suspension rod electroplating	1
33	20070613	ADJUSTING PIN	1




Pozice	Obj.číslo	Popis	Počet
1	20088576	BELT COVER GIGHT	1
2	20082801	Hexagon Head Tapping Screw6.3x11.5	6
3	20061336	FLANGE NUT M8	3
4	20084618	CUT TENTION SUPPORT WELDMENT	1
5	20084542	ADJUSTING SCREW ROD	1
6	20082799	FLANGE BOLTS5/16-18TX3/4	2
7	20070630	BUCKLE NUT M6	4
8	20060893	SCREW M6x16	4
9	20084598	TRACTION SPRING	1
10	20061286	Hexagon bolt M12x1.25x50	1
11	20061649	OIL INJECTION NOZZLE	1
12	20084615	CUT TENTION ARM WELDMENT	1
13	20061359	FLANGE LOCK NUT M12x1.25	2
14	20084617	TENTION PULLEY CUSHION COVER	1
15	20085378	Wheel Axle	2

16	20084596	TENTION PULLEY WELDMENT TTM86,Plating white zinc passivation	1
17	20061610	BEARING 6203-2RZ	1
18	20088559	WHEEL	2
19	20061540	CIRCLE 40	1
20	20061348	FLANGE LOCK NUT M8	3
21	20088582	Deck WELDMENT TTM102 black spray molding	1
22	20084610	RIGHT GUIDE Wheel CUSHION COVER	1
23	20061549	SNAP RING 37	2
24	20061626	BEARING 6301-2RS	2
25	20070536	TENTION PULLEY	2
26	20084604	TENTION PULLEY BOLT LONG TTM86,Blacken	1
27	20084305	BELT TTM102 AA95	1
28	20088710	Clutch lever welding part TTM86	1
29	20070624	WATER NOZZLE	2
30	20055756	O RING 11.2×2.65	2
31	20085899	Plastic expansion rivets	2
32	20083936	RIGHT BLADE Axle	1
33	20061625	Bearing 6204-2RZ	4
34	20071285	Hood, Bearing	2
35	20070638	Pulley	2
36	20061650	FLAT KEY C6×18	2
37	20055114	Washer	2
38	20061472	Spring washer 8	2
39	20061274	FLANGE BOLT M8x20	2
40	20062310	BOLT	1
41	20083934	Left BLADE Axle	1
42	20061265	FLANGE BOLT M8x35	8
43	20061452	SPRING WASHER 12	1
44	20088571	BELT COVER LEFT TTM102 black	1
45	20088737	Deck disc reinforcement plate	2
46	20071282	Pivot tube	2
47	20054352	Cuttter house	2
48	20071283	Spacer ring	2
49	20071286	Washer 50x20.2x2	2
50	20054345	Sleeve	2
51	20071284	Left brade	1
52	20070623	Saucer washer	2
53	20061497	WASHER 10	2
54	20061267	Bolt 3/8-24unf	1
55	20061651	HALFMOON KEY 4×16	2
56	20071289	RIGHT BLADE	1
57	20061266	LH Bolt 3/8-24-1.25"-1.25-LH	1




Pozice	Obj.číslo	Popis	Počet
1	20084300	Screw M6X65	2
2	20085874	Front grass collectorTTM86, K46/T2	1
3	20084482	SPACER $\Phi 6 \times \Phi 10 \times 48$	2
4	20061385	Hexagon lock nut M6	11
5	20085875	Rear grass collector TTM86, K46/T2	1
6	20086201	lock knob	2
7	20070642	Core plug	1
8	20060905	SCREW M6×30	1
9	20070643	Handle	1
10	20071295	Lever	1
11	20086969	Sealing Wool TTM86	1
12	20084479	COVER (starry gray)	1
13	20084469	GRASS COLLECTING FRAME FRONT SUPPORT WELDMENT	1
14	20084472	HANDLE DECPRATIVE PLATE	1
15	20084298	Tapping screw ST4.8x16	6
16	20061246	HEXAGON BOLTM6x35	8
17	20084483	GRASS COLLECTING FRAME STATE SUPPORT WELDMENT	1
18	20084488	Side stay pipe	2
19	20084473	GRASS CATCHER(BOTTOM+CATCHER)	1
20	20084299	Tapping screw ST5.5x35	4




Pozice	Obj.číslo	Popis	Počet
1	20085496	GROUND CABLE	1
2	20088998	Electric cable (electric start)	1
4	20062416	COVER,SWITCH	1
5	20089224	SWITCH,PLUNGER	1
6	20084624	Battery cable	1
7	20070813	Buzzer	1
8	20061492	Axial elastic ring Ø24	1
9	20061186	BOLT M5×16	2
10	20071221	STAR RELAY	1
11	20061341	FLANGE LOCK NUT M5	3
12	20089006	RELAY YAP23H-12-HR	2
13	20062522	Screw M5×12	1
14	20084637	POWER CABLE	1
15	20085696	FUSE BRM148S, 20A	1
16	20062234	SWITCH,PTO	1
17	20089045	SWITCH	1
18	20089345	Electric door lock	1
19	20084634	spring plate	1
20	20086271	SWITCH	2
21	20089223	wire clamp	1
22	20061385	Hexagon flange lock nut M6	4
23	20061334	nut M3	4
24	20084633	Washer 3	4
25	20084622	Switch base	1
26	20060893	Screw M6*16	2
27	20051776	Tapping screw ST4.2*10	1
28	20084640	Hook	1
29	20071233	Switch lever	1
30	20061539	Washer Ø6	1

31	20059765	SPLIT PIN	1
32	20051763	Screw M3*20	4
33	20071232	Switch	1
34	20070744	Belt	1
35	20071324	BATTERY 12V 18Ah	1
36	20084632	HOOK	2
37	20082800	Tapping screwM6*1	2
38	20084636	Switch lever	1
39	20084628	Washer	1
40	20086270	SWITCH	2
41	20061289	BOLT M6×16	2
42	20084629	Switch base	1




Pozice	Obj.číslo	Popis	Počet
1	20061038	SCREW ST4.8×16	27
2	20084507	AIR DIRECTOR	1
3	20084497	SCREW ST4.8×20	2
4	20084504	RIGHT SIDE COVER	1
5	20084511	FRONT COVER	1
6	20070576	SPRING PIN	2
7	20061497	WASHER 10	2
8	20078136	PIN	2
9	20084500	LEFT LIGHT COVER	1
10	20085780	RIGHT LIGHT BASE TTM86,Bright silver plating	1
11	20084627	light	1
12	20085735	Lamp Base cover TTM86, black	4
13	20051768	TAPPING SCREW ST2.9x12	8
14	20084502	LEFT SIDE COVER	1
15	20085779	LEFT LIGHT BASE TTM86,Bright silver plating	1
16	20084508	LEFT LIGHT COVER	1
17	20050895	Ignition wire clamp	4
18	20084496	ENGINE COVER	1
19	20084505	ENGINE COVER AIR INTAKE	1
20	20060893	SCREW M6×16	10
21	20084503	STEERING WHEEL COVER	1
22	20075146	HANDLE ANTI-VIBRATION RUBBER	4
23	20061013	Screw M6X16	3
24	20084494	PANEL	1
25	20070630	BUCKLE NUT M6	17
26	20084495	SHIELD	1
27	20082800	SCREW 6x16	6


28	20084506	MAINTENANCE COVER	1
29	20084509	RIGHT STORAGE BOX	1
30	20084510	REAR SEAT	1
31	20060919	SCREW M6×25	4
32	20084493	LEFT STORAGE BOX	1
33	20084499	REAR COVER TAIL-BOARD	1
34	20084298	TAPPING SCREW ST4.8x16	5
35	20071676	GASKET 6.5×25×1.4	1
36	20084501	STALL DECORATIVE PLATE	1




Pozice	Obj.číslo	Popis	Počet
1	20061254	FLANGE BOLT M8×40	2
2	20085158		1
3	20085165		2




CYLINDER HEAD ASSY			
Pozice	Obj.číslo	Popis	Počet
1	380140103-0004	Hexagon bolt with flange	8
2	120220090-0001	Cylinder head cover assy	2
3	120250071-0001	Gasket for cylinder head cover	2
4	270960046-0001	Spark plug	2
5	380140455-0001	Hexagon bolt with flange	6
6	380140456-0001	Hexagon bolt with flange	4
7	120081016-0001	Cylinder head	1
8	120081017-0001	Cylinder head	1
9	120150261-0001	Gasket for cylinder head	2
10	380600129-0001	ocation pin	4
11	180650074-0001	Outlet gasket	2



CRANKCASE			
Pozice	Obj.číslo	Popis	Počet
1	380650337-0001	Oil seal	1
2	380741376-0001	Breather tube	1
3	380140013-0005	Hexagon bolt with flange	4
4	110840048-0001	CAP,BREATHING CHAMBER	1
5	110850033-0001	PACKING, BREATHING CHAMBER	1
6	662850001-0001	FILTER BLOCK BRACKET	1
7	380450559-0001	Flat washer	1
8	380140067-0003	Hexagon bolt with flange	2
9	140250022-0001	Leaf valve	1
10	380940779-0001	Cable cleat	1
11	380450522-0002	Flat washer	1
12	381350004-0001	Pin clip	1
13	380650339-0001	Oil seal	1




CRANKCASE			
Pozice	Obj.číslo	Popis	Počet
14	171630013-0001	Speed regulating arm	1
15	380140595-0001	Hexagon bolt with flange	2
16	270360154-0001	Components of starting motor	1
17	160190130-0001	air deflector	1
18	380020070-0001	Hexagon shaft shoulder bolt	4
19	110810492-0001	Crankcase body	1
20	160190129-0001	air deflector	1
21	380950400-0001	Pipe clip	1




CRANKCASE COVER


Pozice	Obj.číslo	Popis	Počet
1	110820281-0001	Crankcase cover	1
2	380650770-0001	Oil seal	1
3	380140152-0002	Hexagon bolt with flange	10
4	380600123-0001	ocation pin	2
5	380640016-0001	Steel ball	1
6	381150437-0001	Compression spring	1
7	150350046-0002	Oil filter	1
8	150840002-0002	Oil filter Mounting bolts	1
9	150290044-0001	Engine oil Strainer	1
10	150340022-0001	Cover,Oil Strainer	1
11	380140013-0005	Hexagon bolt with flange	5
12	110830074-0001	Crankcase cover gasket	1
13	380840443-0001	Seal ring	1




CRANKCASE COVER			
Pozic	Obj.číslo	Popis	Počet
14	110950005-0001	Joint of extension bar for bleeding	1
15	380960274-0001	Clip combination	2
16	380751099-0001	Oil tube	1
17	662870001-0001	VALVE-DRAIN, OIL	1
18	150040059-0001	Oil pump cover	1
19	380840665-0001	Seal ring	1
20	150010076-0001	Components of oil pump	1
21	171750051-0001	Components of governor gear	1
22	110690126-0001	Oil rule combination	1
23	380020087-0001	Hexagon shaft shoulder bolt	1
24	380140049-0003	Hexagon bolt with flange	2




CRANKSHAFT PISTON			
Pozice	Obj.číslo	Popis	Počet
1	130070274-0001	Piston ring combination	2
2	130030314-0001	Piston	2
3	380560078-0001	Steel cable baffle ring	4
4	130060085-0001	Piston pin	2
5	130150157-0002	Connecting rod	2
6	130290666-0001	crankshaft	1
7	130180031-0001	Connecting rod bolt	4




ROCKER, CAMSHAFT			
Pozice	Obj.číslo	Popis	Počet
1	140390015-0001	Valve locker	8
2	140380021-0001	Retainer, valve spring	4
3	140340025-0001	Inner spring of valve	4
4	140400012-0001	Valve oil seal	4
5	140360010-0001	Seat, valve spring	4
6	500550103-0001	Valve Kit	2
7	140450035-0002	Valve rocker combination	4
8	140710020-0001	Plate, push rod guide	2
9	140670070-0001	Push rod	4
10	140690017-0001	Lifter, Valve	4
11	140020198-0001	Camshaft assy	1




CARBURETOR			
Pozice	Obj.číslo	Popis	Počet
1	170430106-0001	Carburetor gasket	2
2	180420825-0001	Intake pipe	1
3	380140100-0003	Hexagon bolt with flange	4
4	380180093-0001	Stud	4
5	170430227-0001	Carburetor gasket	2
6	170440120-0001	Heat insulating pad for carburetor	1
7	170022144-0002	Carburetor	1
8	170430184-0001	Carburetor gasket	1
9	173090003-0001	Locker of choke valve pull rob	1
10	170470030-0001	Gasoline pump bracket	1
11	170010045-0001	Fuel filter	1
12	380960287-0001	Clip combination	6




CARBURETOR			
Pozice	Obj.číslo	Popis	Počet
13	380751189-0001	Oil tube	1
14	170460026-0001	Gasoline pump	1
15	380140103-0004	Hexagon bolt with flange	2
16	380020070-0001	Hexagon shaft shoulder bolt	2
17	380741377-0001	Breather tube	1
18	380751200-0001	Oil tube	1
19	380770339-0001	PROTECTIVE SLEEVE	1




FLYWHEEL			
Pozice	Obj.číslo	Popis	Počet
1	270190061-0001	Components of charging current armature	1
2	380190039-0005	Socket head screw	4
3	270020439-0001	FLYWHEEL COMP	1
4	380450702-0001	Flat washer	1
5	380140457-0001	Hexagon bolt with flange	1
6	160180048-0001	Impeller	1
7	160850007-0001	Impeller cover	1
8	380140769-0001	Hexagon bolt with flange	4
9	380140103-0004	Hexagon bolt with flange	4
10	270920452-0001	COIL ASSY.,IGNNTION	1
11	270920453-0001	COIL ASSY.,IGNNTION	1
12	380140013-0005	Hexagon bolt with flange	2
13	380140040-0005	Hexagon bolt with flange	1




FLYWHEEL			
Pozice	Obj.číslo	Popis	Počet
14	270880264-0001	RectifierVariable voltage rectifier	1
15	380900062-0001	Strap	1
16	271280184-0001	Connecting wire	1
17	380900061-0002	Strap	2




FAN COVER ASSY			
Pozice	Obj.číslo	Popis	Počet
1	160210175-0001	Fan cover comp.	1
2	380020086-0001	Hexagon shaft shoulder bolt	3
3	380020087-0001	Hexagon shaft shoulder bolt	1



CONTROL			
Pozice	Obj.číslo	Popis	Počet
1	171610040-0001	throttle return spring	1
2	171590040-0001	Throttle rod	1
3	380140013-0005	Hexagon bolt with flange	2
4	171650059-0001	Choke valve pull rod	1
5	381140626-0001	Tension spring	1
6	171680211-0001	Throttle handle combination	1
7	173090003-0001	Locker of choke valve pull rod	1
8	171620065-0001	Speed regulating bracket	1
9	171600158-0001	Governing spring	1
10	171610048-0001	throttle return spring	1
11	175400001-0001	bracket	1



AIR CLEANER			
Pozice	Obj.číslo	Popis	Počet
1	180280170-0001	Air filter seat	1
2	381000305-0002	Caulking	1
3	380370066-0001	Hexagon nut with flange	4
4	180100123-0001	Air filter element combination	1



Muffler			
Pozice	Obj.číslo	Popis	Počet
2	380180109-0001	Stud	4
3	380460001-0006	Elastic washer	4
4	380340005-0005	Hexagon nut	4