


Spare parts list for RPB 3342 B Engine

Pos no	Reference	English name	QTY
1	GC305.3B-16308	Knob	1
2	GC305.3B-16301	Cover-Air Filter	1
3	YD4500-90029	Screw M5X50 /GB/T 70.1	2
4	GC305-93014	Gasketφ14Xφ5X1/GB/T 97.1-2002	1
5	GC260.2-24005	Spring Choke	1
6	YD2500-93012	Gasketφ10Xφ5X1/GB/T 97.1-2000	1
7	GC260.2-16309.1	Inbuilt-Air Filter(Short)/φ5Xφ7X8	1
8	GC305.3B-24006	Choke Knob	1
9	GC260.2-16309.2	Inbuilt-Air Filter(Long)	1
10	GC305.3B-16211	Air Filter	1
11	GC305-18200	Carburetor (Walbro)	1
12	GC305-18204	Gasket Carburetor	1
13	YD6200-97004	Screw M5X20/GB/T 9074	18
14	GC305-16111	Boot-Intake	1
15	GC305-16001	Washer-Intake	1
16	GC305.3-26200	Spark Plug	1
17	GC305.3-18315	Insulation pad	1
18	GC305.3-11301-1	Cover Cylinder(yellow1375)	1
19	GC305-97011	Screw M5X14/GB/T 9074	2
20	YD6200-97004	Screw M5X20/GB/T 70.1	1
21	GC305-12111	Cylinder /ZH1E36F-5-3	1
22	GC305-12501	Gasket Cylinder	1
23	GC305.3-21001	Washer-Muffler	1
24	GC305-21110	Muffler Assy	1
25	GC305-97010	Screw-Muffler M5X55 GB/T9074.14-1988	2
27	GC305-26151	Wire Switch	1
28	GC305.3-26110	Ignition strator	1
29	LJ230B-97006	Screw M5X25 GB/T9074.14-1988	2
30	GC305.3-14323	Crankcase Side Cover	1
31	GC30-22133	Screw Clutch	2
32	YD6200-94031	Pin φ5X10 /GB/T 119.1-2000	2
33	GC30-93402	Washer φ10 /GB/T 95-1987	2
34	GC305-22112	Hoof Block Clutch	2
35	GC305-22132	Spring Clutch	1
36	GC305-93004	Washer φ8 /GB/T 97.1-2000	2
37	YD2500-92102	Nut M8 /GB/T 6177.1	1
38	GC305-15110	Flywheel	1
39	YD3800-95012	Seal Oil Fb12X22 /GB/T 9877.1	2
40	LJ230B-97007	Screw M5X30 /GB/T 9074	4
41	GC305-13101	Right Crankcase	1
42	GC305-94602	Key Fly Wheel 3X12/GB/T 1099	1
43	YD6200-94031	Pin φ5X10 /GB/T 119.1-2000	2

44	YD2500-96013	Bearing Ball6202 /GB/T 276	1
44-1	YD2500-96011	Bearing Ball6201	1
45	GC305-14110	Crack shaft	1
46	GC305-96119	Needle Bearing Ballk9X12X12 /JB 2581	1
47	GC305-14002	Ring Snap	2
48	GC305-14211	Piston	1
49	GC305-14001	Piston Pin	1
50	GC305-14311	Piston Ring	2
51	GC305-13090	Gasket Crankshaft	1
52	GC305-13201	Left Crankcase	1
53	GC305-25260.2	Pulley Assy For Easy Start	1
54	YD2500-91332	Screw For Pulley Start(Easy Start)/GB/T 845	1
55	YD2500-93011	Start Shaft $\Phi$ 5X10 /GB/T 97.1-2002	1
56	GC305-25215.2	Start Rope	1
57	GC305-25112	Spring Easy Start	1
58	GC305-25301	Start Rope	1
59	GC305-25211.2	Start plate-easy starter	1
60	GC305-25212.2	Coil Spring For Easy Start	1
61	GC305-25110.2	Housing Start Easy Start	1
62	GC305-25311	Start Handle	1
63	GC305.3-18303	Support Fuel Tank	1
64	YD4500-25318	washer-starter handle	1
65	GC305.3B-24008	Sheath--Choke Knob	1
66	GC305-18032	Fuel Cap	1
67	GC305-18209	Fuel Filter Vert	1
68	GC305-17402	Venthole	1
69	GC305-17133	Support-Venthole	1
70	GC305-18033	Gasket Fuel Cap	1
71	GC305-18208	Inside lid	1
72	GC305-18031	Chain	1
73	GC3305-18101.1	Fuel Inlet	1
74	GC3305-18101.2	Fuel Outlet	1
75	GC305-18104	Support-Fuel Pipe	1
76	GC305-18034	Fuel Filter	1
77	GC305.3-18303	Fuel Tank	1
78	GC305.3-18213.1	Support Fuel Tabk	1
79	GC305.3B-16205	Gasket-air filter	1
80	GC305.3B-16313	Air Filter	1
ZC1	GC305-25000	Start Assy	1
ZC2	GC305-14000	Crank Shaft+Piston Assy	1
ZC3	GC305-18030	Fuel Cap Assy	1
ZC4	GC305-22110	Clutch Assy	1
ZC5	GC305-18300	Fuel tank assembly	1



## Spare parts list for RPB 3342 B transmission

Pos no	Reference	Parts name	QTY
1	GC305.3B-42000	PNBC305-3b ENGINE ASSY	1
2	GC260-42109	transmission shaft	1
3	GC305-45300	oil bearing	6
4	GC260-45103	aluminium tube	1
5	GC415-42116	connect shaft	1
6	GC305.3A-43030	Handle	1
7	GC305-47081	slide switch	1
8	GC305-47084	hander left part	1
9	YD2500-92001	nut GB/T41-2000/M5	1
10	GC305.3A-47086	trigger control arm spring	1
11	GC305.3A-47090	flameout wire	1
12	GC305.3A-47088	trigger control arm	1
13	GC305.3A-47083	spring-flameout switch	1
14	GC305.3A-47112	Spring	1
15	GC305.3A-47113	screw ST3.9X15	1
16	GC305.3A-47114	Support	1
17	GC305.3A-47092	trigger spring	1
18	GC305.3A-47091-1	trigger (1375yellow)	1
19	GC305.3A-47094	hander right part	1
20	GC305-91327	tapping screw GB/T 845-1986/ST3.9X15	3
21	GC305-90305	screw GB/T 818-1986/M5X30	1
22	GC305.3B-43023	screw	1
23	GC305.3B-43011	up cap	1
24	GC305.3B-43012	down cap	1
25	GC305.3B-43019	spring	1
26	GC305.3B-43016	up clip	1
27	GC305.3B-43018	down clip	1
28	GC305.3B-93113	washer	2
29	GC305.3B-90013	screw GB/T 9074/M5X16	2
30	YD4500-90022	screw GB/T 70.1/M5X20	1
31	YD2500-92001	Nut GB/T41-2000/M5	1
32	GC305-46580	Harness	1
33	GC305-46582	support-pothook	1
34	GC305-46581	pothook	1
35	GC305.3A-98101	screw GB/T 12618-1990/5X10	1
36	GC305-90012	screw GB/T 70.1/M6X25	2
37	GC305-98201	Washer GB/T861.2-1987	2
38	GC305.3A-48050	plate-cover	1
39	GC305.3A-48116	Cable clip	1
40	GC305.3A-48118	Cable clip	2
41	GC305-22121	clutch cover	1
42	GC305-93215	spring ring GB/T89301-1986/Φ36	1
43	GC305-96019	ball bearing GB/T 276-1994/6202RS	1

44	GC305-93217	spring ring GB/T894.1-86/Φ15	1
45	GC305-44324.2	export house	1
46	GC305.1-97013	screw GB/T 9074/M6X30	4
47	GC305-44323.2	Export support lining	1
48	GC305-44327	tube fixed	1
49	GC305-90012	screw GB/T 70.1/M6X25	1
50	YD3800-90024	screw GB/T 70.1/M5X20	1
51	YD3800-93211	spring ring GB/T 89301-1986/Φ32	1
52	GC305.3A-48054	Block grass board	1
53	GC305.3B-48060	support-Block grass board	1
54	GC260-42108	transmission shaft	1
55	GC305.3B-48056	Small blade	1
56	GC305.3B-91337	screw GB/T 845-1986/ST4.8X14	1
57	GC305.3A-48061	screw/ST4.2X32	2
58	GC305-93214	spring ring GB/T 893.1-1986/Φ26	1
59	GC3051-93216	spring ring GB/T894.1-86/Φ10	1
60	GC305-96017	bearing GB/T 276-1994/6200RS	3
61	GC305-48041	Export umbrella gear	1
62	GC305-48042	gear box shell	1
63	YD2500-90025	screw GB/T 70.1/M5X25	1
64	GC305-97304	screw GB/T 9074.4-1988/M6X10	1
65	GC305-48043	Export umbrella gear	1
66	GC305-96018	bearing GB/T 276-1994/6002Z	1
67	GC305-48044	export axle	1
68	YD3800-93211	spring ring GB/T 893.1-1986/Φ32	1
69	GC305-48045	protect cover	1
70	GC305.1-97303	screw GB/T 9074.4-1988/M5X10	3
71	LJ230B-93003	washer/Φ5	1
72	YD3800-90021	screw GB/T 70.1/M5X10	1
73	GC305-48046	up pressing plate	1
74	GC305-48047	down pressing plate	1
75	GC305-48048	cover board	1
76	GC305.1-92105	nut GB/T 6183.1-2000 /M10	1
77	GC305-48233	Bump head cover	1
78	GC305-48235	Return spring	1
79	GC305-48185	Trimmer line	1
80	GC305-48236	trimmer line plate	1
81	GC305-48237	support-nylon cutter	2
82	GC305-48238	bump head base	1
83	GC305-48200	Three tooth blade	1
84	GC415-45113	aluminium tube	1
85	GC260-42158	Handle-Limit pin	1
86	GC260-42157	Limit pin	1
87	GC260-42145	Limit pin support	1
88	GC305.3-42150	Connect sheath	1
89	GC260-42150.1	Tighten handle screw	1
90	YD3800-90021	screw GB/T 70.1/M5X10	1

91	GC305-90012	screw GB/T 70.1/M6X25	1
92	GC260-42156	cage	1
ZC1	GC305-44300.2	export support assy	1
ZC2	GC305.3A-43010	handle holder assy	1
ZC3	GC305.3A-47080-1	control handle assy ( 1375yellow trigger)	1
ZC4	GC305-48040	gear box assembly	1
ZC5	GC305-48180	nylon cutter assy	1